

Assembly and Operating Instructions

RMX Mixer Stand



Collomix GmbH
Daimlerstr. 9
85080 Gaimersheim
Germany
www.collomix.com



For the operation with a hand-mixer, please pay attention to the instruction manual of the machine as well as to the „General safety notes for power tools“.





Hold the round pipe in the depressed position and swivel the square pipe to the side. When the release is actuated, the spring force will press the swivel arm upwards.



CAUTION: The pipe will be pushed up suddenly by the spring force - beware of injury!



Hang the Xo mixer by its two holes into the mount.



Secure the mixer firmly with the screws; if necessary use a tool to tighten the screws



For mixing: push the machine into the material and move to all sides. To support while starting, press the tube with your second hand downwards to get the mixer lowered easily; grease the tube slightly



The machine cannot be operated on its own with the RMX. Always operate the mixing machine with two hands on the machine. Start up and run down the machine in the mixing container only. Ensure that the mixing container is stood in a firm and secure position. It is not allowed to block the ON-/OFF switch of the mixer for operation!